

# Looking after your TT 4045 / 4055

## Pre-sweep Floor

"Floors must be swept"  
BEFORE attempting to use your machine.



## Clean Separator



## Empty Top (Waste) Tank



## Clean Waste Basket



## Clean Floor-tool



## Check for Hose Blockages



[www.numatic.co.uk](http://www.numatic.co.uk)



[www.numatic.fr](http://www.numatic.fr)



[www.numatic.de](http://www.numatic.de)



[www.numatic.nl](http://www.numatic.nl)



[www.numatic.ch](http://www.numatic.ch)



[www.numatic.co.za](http://www.numatic.co.za)

Numatic International Limited, Chard, Somerset, TA20 2GB Tel: +44 01460 68600 Fax: +44 01460 68458  
Specification subject to change without prior notice.

Please read the operating instructions provided with your TwinTec machine.



Simply peel off above sticker and carefully stick to a dry, clean and flat service. Begin by sticking the top of the poster, slowly smoothing the material working downwards.

This material is a specially developed vinyl that will stick to many surfaces including concrete, brick, plaster and is also re-positionable.

If you are unsure of the suitability of a surface cut a sample using this lower section to stick to a test area. Numatic international Ltd. accept no responsibility for any damage caused by adhering / removing this sticker from an unsuitable surface. Printed using Arlon DPF 4300 (Data Sheet included).

Do not stick to fire doors / barriers or obscure existing signage.